

# JennSwing or JennSwing Cubby II Replacement Harness Instructions

**Installation:** To install the harness, unsnap the crotch strap from the rest of the harness. Thread short belt through the back crotch hole and come back up through the front hole, thread strap through back hole of the buckle from the bottom, then down through the front hole. Adjust as needed. Take the "I" shaped buckle and thread up through the front of the male buckle that says rock lockster then thread the strap down through the back hole of the same clip. Clip to crotch strap. Pull out one side of the thin strap from upper buckle and thread through the top of seat hole from front to back and come up through left side top hole. Then rethread through buckle to adjust to adjustment strap. Connect to buckle on wide strap that is the other buckle on the "I" buckles. Adjust straps to fit child.

**Harness Installation YouTube:** Video can view viewed here:

<https://www.backyardcity.com/Swing-Set-Accessories/JennSwing-Harness.htm>

**Safe Use:** This is for use of up to 125 pounds (JennSwing) and 60 pounds (Cubby) only. Not for adult use. Adults should supervise children at all times. Do Not allow children to stand on seat or use for any other use that intended in description. Do not allow it to be used if damaged.

**Maintenance:** Do monthly routine maintenance checks for cracks, rust, open S-hooks, chain and eyebolts for wear to reduce unnecessary injuries. Replace any worn, damaged or vandalized parts. Make sure there are no exposed footings, anchoring devices, rocks, roots, holes or any other obstacles in or around playground equipment. This will reduce serious injuries. in high use areas these inspections should be done more frequently. Clean with mild soap and water when you do the monthly maintenance checks.

Any damage from vandalism, abuse or misuse, **VOIDS** all warranties.